

LENGO Trim Tab Wiring Schematic (ISO LED, standard tactile pad) Part # 30006-001D

Activator wire ends

Switch wire ends

white	—●—	blue	(starboard bow down - port tab goes down)
black	—●—	white	(common)
red	—●—	yellow	(port bow up - starboard tab comes up)
green	—●—	red/black	(starboard bow up - port tab comes up)
brown	—●—	green	(port bow down - starboard tab goes down)

not used {
 brown/black
 green/black
~~red/black~~ black
 red
 white/black

Brown Black	white Black
Green Black	yellow
Blue	Red Black
Green	white
Red	Black

back view of
switch pad